

Title Page - O'Day 30
Important Safety Information
Limited 1-Year Warranty
Congratulations

C O N T E N T S

I	GENERAL
	Dimensions and Capacities
	Docking Plan
	Sail Plan
	Arrangement Plan
	For Owner's Use - Blank Interior Layout
	Dealer Responsibilities
	Owner's Responsibilities
II	COMMISSIONING
	Commissioning
	Pre-Launch Check List
	Post-Launch Check List
	Commissioning Notes
	Isomat Spars - Mast Wedge and Pin Instructions
	Rubber Wedges Drawing
	Pin Drawing
	Stepping and Tuning the Mast
	Chainplate Rods - O'Day 28, 30, 34, 39
	Rigging Dimensions
	Running Rigging Specifications
	Standing Rigging Specifications
	Isomat Boom Rigging Instructions
	Boat Storage
III	OPERATION
	Engine Operating Instruction
	Flooding of Engine with Water
	Fuel System Schematic - Diesel
	Fueling Procedure
	Wheel Steering
	Electrical
	Lightning Ground
	Navigation Lights
	Thru-Hull Fittings
	Water System and Through Hull Fittings Schematic
	Pressure Water System (Optional)
	Head Operation
	Cooking Stove/Propane Stoves
	Alcohol Stoves
IV	MAINTENANCE
	Finishes
	Basic Rules for Battery Care and Maintenance
	Stanchion Gaskets
	Periodic Maintenance
	Periodic Maintenance Schedule
V	MANUALS